

Lifetime Guarantee

The PL-870 is guaranteed against any mechanical defects. If it malfunctions, return it for repair or replacement free of charge.

Please include a \$2.00 shipping and handling fee and send to:


Prime Service Center
P.O. Box 9715
Stratford, CT 06497



PL-870

Radio with Carabiner

Compact FM Scan Radio



LE-0870-000

Instructions

Use the carabiner to clip it to your belt loop, purse or back pack to keep it within easy reach.

1. Plug the ear buds into the radio (A)
2. Carefully insert ear buds into your ears.
3. Turn on the radio and adjust the volume by sliding the switch (B) toward the earbud jack. This switch has three positions: Off / Low Volume / High Volume
4. Press the reset button (C) to set the tuning to the lowest FM frequency (88MHz).
5. Press the scan button (D) to automatically tune in the next higher FM station strong enough to be received. Upon pressing reset or scan, wait a few seconds for the radio to tune itself. Once the frequency reaches the top end of the FM dial (108MHz), press reset to bring it back to the lowest frequency.
6. If radio signals aren't strong or the volume is low, replace the two button cell batteries as shown in diagram (E).

